

DELICI

دليل المستخدم
الأواني الممانعة للالتصاق

Non-Stick Cookware
User Guide



FOOD GRADE



GAS



CERAMIC



HANDLE WITH CARE

A large, light grey, stylized swirl graphic that forms a circular shape with a white center. The swirl starts from the top left and curves clockwise, ending at the bottom left.

User Guide

 DELICI

INSTRUCTION FOR USING NON-STICK COOKWARE

- Before first use the pan needs to be conditioned. Apply a little oil and heat the pan. After it cools, clean with a soft cloth and soapy water.
- Always cook in low to medium flame.
- Do not use sharp objects like knives, forks and metal spoons with sharp edges. Use only manufacture-recommended spatulas.
- If anything sticks on pot, don't rub it forcefully. Keep water in the pot for some time and clean with soapy water.
- Don't use hard or metal scrubber for cleaning.
- Cool pans before washing with plain water.
- Use liquid detergent, not hard deterrgent.
- Keep the non-stick cookware together with care to avoid scratches.

تعليمات استخدام الأواني المانعة للالتصاق

- قبل الاستخدام للمرة الأولى، تجب تهيئة المقلاة. ضع كمية صغيرة من الزيت في المقلاة وسخنها. وبعد أن تبرد، نظفها بقطعة قماش ناعمة وماء بصابون
- احرص دائماً على الطهي على ألسنة لهب منخفضة إلى متوسطة
- لا تستخدم أغراضاً حادة، مثل السكين والشوكة والملاعق المعدنية ذات الحواف الحادة. بل استخدم فقط الملاعق المصنوعة من الخشب أو الخيزران أو النايلون
- إذا التصق أي شيء بالقدر، فلا تحكّه بقوة. احتفظ بالماء في القدر لبعض الوقت، ثم نظف بماء وصابون
- لا تستخدم مكشّطة أواني صلبة أو معدنية عند التنظيف
- قم بترديد المقلاة قبل الغسل تحت الماء الجاري
- استخدم منظفًا سائلًا، وليس منظفًا قويًا
- احتفظ بالأواني المانعة للالتصاق معًا بحرص لتجنب تعرضها للخدوش